


End View of PC Power Connector.

Care needs to be taken not to spread the pins when removing the power feed connector from the drive.

Technicians should check and ensure that the gap is closed on the connector pins before fitting the power feed connector back onto the drive.



**TECHNICIANS SHOULD ADJUST THE GAP ON CONNECTOR 1 & 2
Before fitting the drive**